

Features & Restrictions

The online ETAP demonstration program contains some limitations not present in the commercial version:

- x The demo trial period is for 30 days contact <u>sales@etap.com</u> for options beyond expiration date.
- x Create / Edit projects with up to Twelve (12) AC buses and Ten (10) DC buses.
- x View Getting Started videos, sample projects, and other how-to videos.
- x The demo is limited to Five (5) Star View (TCC) presentations.
- x Saving and opening existing ETAP projects are disabled.
- x Printing output reports are restricted to the original example project reports.
- x The displayed results on the one-line diagram and the plots are based on the modifications made.
- x Data Exchange functions are disabled.
- x Components can be added to / modified onto the one-line diagram.
- x Distribution Panel Boards have some limitations such as disabled Summary page, Report Manager Printing, Library Quick Pick Window, and fixed number of circuits.
- x Sample Engineering Library is provided. Adding and copying functionality in the Library is disabled.

Modules available by default in the cloud-based demo version

- x Auto-Build and Rule Book One-Line Diagram
- x Load Flow
- x Wind Turbine Generator and PV Array Elements
- x Panel Systems
- x Short Circuit (ANSI, IEC)
- x Star[™] Protective Device Coordination
- x Star Sequence-of-Operation
- x AC Arc Flash
- x Motor Acceleration (Dynamic and Static)
- x Harmonics (Load Flow and Frequency Scan)
- x Transient Stability
- x Unbalanced Load Flow / Open Phase Fault
- x Optimal Power Flow
- x Load Analyzer
- x DC Load Flow
- x DC Short-Circuit
- x DC Arc Flash
- x Battery Sizing & Discharge
- x Reliability Assessment
- x Optimal Capacitor Placement

+1.800.477.ETAP | +1.949.900.1000 | info@etap.com

etap.com



Features & Restrictions

